

# Removing Radioactive Contamination

- Contamination detected using contamination monitors should be removed until  $\text{cps} = \text{background cps}$ .
- Contamination detected by wipe testing should be removed until  $\text{cps} < \text{twice background}$ .
- When contamination cannot be removed, consult your RPS.

**Note:** Remember to check the back wall of the dispensing area as part of your regular contamination monitoring routine.